

Swash Plate Type Axial Piston Pump K3VLS Series



CONTENTS

I . Applications / Product Usage	2
II. Safety Precautions	3
■. Handling Precautions	4
IV. Conversion Factors, Formula and Definition	8
●K3VLS Series Swash Plate Type Axial Piston Pump	
Specifications, General Descriptions, and Features	10
1. Ordering Code	
1-1. Pump Options	11
1-2. Regulator Options	12
2. Technical Information	
2-1. Specifications	13
2-2. Functional Description of Regulator	
◆Load Sensing and Pressure Cut-off	14
◆Pressure Cut-off	15
◆Torque Limiter	16
◆Torque Limiter with Power Shift	18
◆Electric Displacement Control (Positive Control)	20
3. Dimensions	
3-1. Installation Dimensions	
◆K3VLS50	22
◆K3VLS65	30
◆K3VLS85	39
◆K3VLS105	46
◆K3VLS125/150	54
3-2. Installation of Auxiliary Pumps	60
K3VLS Series Inquiry Form	62

I. Applications / Product Usage

The following must be taken into consideration before use.

- 1. The operating condition of the products shown in this catalog varies depending upon each application. Therefore, the product suitability must be judged by the designer of the hydraulic system and/ or the person who finalizes the technical specifications of the machine after analysis and testing. The product specification shall be determined based on the latest catalog and technical documents. The system must be designed taking into account the possibility of machine failure to ensure that all safety, warning, and application requirements are met.
- 2. For the proper use of the products, descriptions given in the SAFETY PRECAUTIONS must be observed.
- The technical information in this catalog represents typical characteristics and performance of the products as of the published date.

- 4. If the intended use of the products is included in the following, please consult with Kawasaki in advance.
 - (1) Use the product in the operating conditions or environments other than those described in the technical documents.
 - (2) Use the product in the nuclear sector, aviation sector, medical sector, and/or food sector.
 - (3) Use the product in applications which may cause substantial harm to others and their property, and especially in applications where ensuring safety is a requirement.
- 5. The information described in this catalog is subject to change without notice. For the latest information, please contact Kawasaki.

II. Safety Precautions

Before using the product, you MUST read this catalog and MUST fully understand how to use the product. To use the product safely, you MUST carefully read all Warnings and Cautions in this catalog.

1. Cautions related to operation



- Use the personal protective equipment to prevent injury when the product is in operation.



- Some components are heavy. Handle the product carefully not to hurt your hands and lower back.



- Do not step on, hit or drop, or apply strong force to the product, as these actions may cause operation failure, product damage, or oil leakage.



- Wipe off any oil on the product or the floor completely, as oil can create slippery conditions that may cause drop of the product and personal injury.

2. Warnings and cautions related to installation and removal of the product



- Installation, removal, piping, and wiring must be done by a qualified technician.



- Make sure that the hydraulic power unit is turned off and that the electric motor or engine has completely stopped before starting installation or removal. You must also check that the system pressure has dropped to zero.



- Make sure that the power source is turned off before installing electric components to reduce the risk of electric shock.



- Clean the threads and the mounting surface to prevent damage or oil leakage. Inadequate cleaning may cause insufficient torque and broken seals.



- Use the designated bolts and fasten them with prescribed torque when installing the product. Use of undesignated bolts, and excessive or insufficient tightening torque may induce operation failure, damage, or oil leakage.

3. Warnings and cautions for operation



- Always equip the product with explosion or ignition protection if it is used in potentially explosive or combustible atmospheres.



- Shield rotary parts, such as the motor and pump shaft, to avoid injury.



- Stop operation immediately, and take proper measures when the abnormality such as unusual noise, oil leakage, and smoke is found. Continuing operation under such condition may bring about damage, a fire hazard, or injury.



- Make sure that all pipes, hoses, and connecting points with pipes or hoses, are correctly connected and tightened before starting operation.



- Use the product under the operating conditions and limitations described in the catalog, drawings, and specification sheets.



- Do not touch the product in operation. to reduce the risk of skin burn.



- Use the proper hydraulic oil and maintain the filtration at the recommended level to prevent premature wear and damage.

4. Cautions related to maintenance



- Never modify the product without approval from Kawasaki.



- Disassembly of the product may void the warranty.



- Keep the product clean and dry when storing or transporting.



- The seals may need to be replaced if the product has been stored for an extended period of time.



- Making adjustments of this product will result in the warranty being null and void.

1. Operating Fluid and Temperature Range


1) Operating fluid

Values shown in this catalog are based upon using mineral oil based anti-wear hydraulic fluid. To ensure optimal performance use of mineral oil based anti-wear hydraulic fluid is recommended.

2) Viscosity and temperature range

To minimize both oil and seal deterioration, a maximum operating temperature of 60°C should be considered. Please note that the regulator may become slow to respond when operating at low temperatures (below 20°C) in extreme cold environments. At such low temperature it is strongly suggested that a warm up cycle is introduced until an operating temperature of 20°C is achieved

	Normal operating range	Allowable range	
Viscosity [mm²/s(cSt)]	10 to 200	10 to 1,000	
Fluid temperature [°C (°F)]	-20 to +95 (-4 to +203)		



Normal operating range

2. Filtration and Contamination Control

1) Filtration of working oil

The most important means to prevent premature damage to the pump and associated equipment and to extend its working life, is to ensure that hydraulic fluid contamination control of the system is working effectively.

This begins by ensuring that at the time of installation that all piping, tanks etc. are rigorously cleaned in a sanitary way. Flushing should be provided using an off line filtration system and after flushing the filter elements should be replaced.

A full flow return line filter of 10 micron nominal should be utilised to prevent contaminant ingress from the external environment, a 5 to 10 micron filter with the tank's breather is also recommended.


2) Suggested acceptable contamination level

The relationship between contamination level and pump life is very difficult to predict as it depends on the type and nature of the contaminant present in the system. Sand or Silica in particular, due to its abnrasive nature, does significantly reduce the expected life of a pump. Based on the precondition that there is no significant presence of Silica type substances then a minimum Cleanliness level of -/18/15 ISO 4406 or SAE AS 4059E Table 1 Class 9 (NAS 1638 Class 9).

3. Drive Shaft Coupling

Alignment between the prime mover and the pump shaft should be within 0.05 mm TIR*. In case the pump is directly coupled to the engine flywheel, use a flexible coupling.

*TIR = Total Indicator Reading



4. Oil Filling and Air Bleeding

1) Pump case filling

Be sure to fill the pump casing with oil through the drain port, filling only the suction line with oil is totally in-sufficient. The pump contains bearings and high-speed sliding parts including pistons with shoes and a spherical bush that need to be continuously lubricated. Part seizure or total premature failure will occur very quickly if this procedure is not rigidly followed.

2) Air bleeding

Run the pump unloaded for a period to ensure that all residual air within the system is released.


3) Long term out of usage

It is undesirable to leave the pump out of use for a long period e.g. a year or more. In such a situation it is recommended that the pump is run for a short period on a more frequent basis even if it is just unloaded. With regard to a pump held in storage then rotating the shaft on a frequent basis is sufficient. If the pump is left out for more than the suggested time it will require a service inspection.

5. Drain Piping

1) Installation of drain line


It is the preferred option to mount the pump with the case drain piping initially rising above the pump before continuing to the tank. Do not connect the drain line to the inlet line.



Cautions

- **A)** Inlet and drain pipes must be immersed by 200 mm minimum from the lowest level under operating conditions.
- **B)** Height from the oil level to the centre of the shaft must be within 1 meter maximum.
- **C)** The oil in the pump case must be refilled when the pump has not been operated for one month or longer.

The uppermost drain port should be used and the drain piping must be larger in size than the drain port to minimise pressure in the pump case. The pump case pressure must not exceed 0.1 MPa as shown in the illustration below. (Peak pressure must never exceed 0.4 MPa.)




2) Size of drain hose or drain pipe

The internal bore size of the drain hose or drain pipe must be larger than that of the drain port. Arrange the drain line as short as possible.

6. Mounting the Pump Above the Tank

Suction line



7. Shaft Loading and Bearing Life

Although K3VLS pumps are equipped with bearings that can accept some external thrust and radial forces, application of such loads will affect bearing life. Depending on the load magnitude, the load position, and the load orientation, bearing life may be significantly reduced.

IV. Conversion Factors, Formula and Definition

Conversion Factors

	Formula	Note
Displacement	$1 \text{ cm}^3 = 0.061 \text{ in}^3$	
Pressure	1 MPa = 145 psi	
Flow	1 L/min = 0.264 gpm	US gallon
Torque	1 Nm = 0.74 lb ft	
Power	1 kW = 1.341 hp	
Weight	1 kg = 2.205 lb	

Formula

	Metric system		Imperial system	
Output flow	$Q = q \times N \times \eta_{v} / 1000$	L/min	$Q = q \times N \times \eta_{v} / 231$	gal/min
Input torque	$T = q \times \Delta P / 2\pi / \eta_m$	Nm	$T = q \times \Delta P / 24\pi / \eta_m$	lbf ft
Input power	L = T x N / 9550 = Q x Δ P / 60 / η_{t}	kW	L = T x N / 5252 = Q x Δ P / 1714 / η_{t}	hp


Definition

q	=	Pump displacement / rev.	cm³ (in³)
L	=	Input power	kW (hp)
N	=	Speed	min ⁻¹ (rpm)
ΔΡ	=	$P_d - P_s$	MPa (psi)
Pd	=	Pump delivery pressure	MPa (psi)
Ps	=	Pump suction pressure	MPa (psi)
PL	=	Load sensing pressure	MPa (psi)
Pdr	=	Pump case pressure	MPa (psi)
Pf	=	Power shift pressure	MPa (psi)
Psv	=	Servo pressure	MPa (psi)
Т	=	Input torque	Nm (lbf-ft)
T _{max}	=	Maximum input torque	Nm (lbf-ft)
$\eta_{_{ ext{ iny }}}$	=	Pump volumetric efficiency	
η_{m}	=	Pump mechanical efficiency	
$\eta_{_{\mathrm{t}}}$	=	Pump total efficiency	
		-	

MEMO

K3VLS Series

Swash Plate Type Axial Piston Pump



■Specifications

Size: 50, 65, 85, 105, 125*, 150

Rated Pressure : 28 MPa Peak Pressure : 35 MPa

■General Descriptions

The K3VLS are variable displacement axial piston pumps of swash plate design, suitable for use in mobile applications and industrial vehicles with medium pressure hydraulic systems.

The K3VLS pumps enable flexible configuration in a wide range of applications with their compact size and light weight design.

The K3VLS series pumps are available in size (rated displacement) ranging from 50 to 150 cm³/rev with various control options, such as load sensing, pressure cut-off, and horsepower controls.


■Features

- Variable axial piston pump of swash plate design in open circuits
- High overall efficiency
- Compact size
- Light weight
- Excellent reliability
- Numerous control options
- High stability
- Highly responsive controls
- (*) means under development

1 Ordering Code

1-1 Pump Options

Please fill in the Inquiry Form on page 62 in order to specify the requirement.



1. Ordering Code

1-2 Regulator Options

Please fill in the Inquiry Form on page 62 in order to specify the requirement.

	1 2 3 Model Code K3VLS 105	3 4 5 - 1 B l			7 CC			9 L1	1 /
								\top	
. FIO	bw Control			0.5	105	125	1 [0]		
10	Load Sense & Pressure Cut-Off	50	_	85	105		_		
L0 L1			•		•	0			
	Pressure Cut-off				•	0			
PU	Pressure cut-on								
0. D	ifferential Pressure Setting Range (For the details see page 14	1) ———							
0. 5	The cities is a second name (i or the details see page 1)		65	85	105	125	150		
Α	Standard Setting Range (1.0 to 3.0MPa)	•	•	•		0	•		
C	High Setting Range (1.5 to 4.0MPa)	•	•	•		0	•		
	dditional Control Options (For the additional control options "11", only				accep 105	125	150		
Blank	Without Any Additional Control					0			
	Torque Limit Control	50	65	85	105	125	150		
Α	Without Power Shift Control	•	•	•	•	0	0		
В	With Power Shift Control, Pilot Operated	•	•	•	•	\circ	0		
	With Electric Proportional Reducing Valve								
C2	Voltage:24V, Deutsch Connecter	0	0	0	0	\circ			
С3	Voltage:12V, Deutsch Connecter	0	0	0	0	0			
	Electric Displacement Control (Positive Control)	50	65	85	105	125	150		
	With Fail-safe Function								
E2	Voltage:24V, Deutsch Connecter	•	•	0	-	-	-		
				1					
E3	Voltage:12V, Deutsch Connecter	•			-	-	-		
	Voltage:12V, Deutsch Connecter Without Fail-safe Function	•	•	0		-	-		
	Without Fail-safe Function	•	•	0	0	-	0		
E3	Without Fail-safe Function Voltage:24V, Deutsch Connecter	•	•	0	0	- 0 0			
E3 F2 F3	Without Fail-safe Function Voltage:24V, Deutsch Connecter Voltage:12V, Deutsch Connecter	•	•	0	0	- O O	0		
F2 F3	Without Fail-safe Function Voltage:24V, Deutsch Connecter			0	0	0	0		
F2 F3	Without Fail-safe Function Voltage:24V, Deutsch Connecter Voltage:12V, Deutsch Connecter orque Limit Setting (Available only with the attachment of Tor	que Limiter,		0	105	125	150		
F2 F3 2. T (Without Fail-safe Function Voltage:24V, Deutsch Connecter Voltage:12V, Deutsch Connecter orque Limit Setting (Available only with the attachment of Tor Without Any Torque Limit Setting	50	65	85	105	125	150		
F2 F3 2. T (Blank H1	Without Fail-safe Function Voltage:24V, Deutsch Connecter Voltage:12V, Deutsch Connecter orque Limit Setting (Available only with the attachment of Tor Without Any Torque Limit Setting H Spring, Corner Torque 85%		65 •	0	105	125	150		
F2 F3 2. T (Blank H1 H2	Without Fail-safe Function Voltage:24V, Deutsch Connecter Voltage:12V, Deutsch Connecter orque Limit Setting (Available only with the attachment of Tor Without Any Torque Limit Setting H Spring, Corner Torque 85% H Spring, Corner Torque 75%	50	65	85	105	125	150		
F2 F3 2. T 0 Blank H1 H2 H3	Without Fail-safe Function Voltage:24V, Deutsch Connecter Voltage:12V, Deutsch Connecter orque Limit Setting (Available only with the attachment of Tor Without Any Torque Limit Setting H Spring, Corner Torque 85% H Spring, Corner Torque 75% H Spring, Corner Torque 65%	50	65 • •	85	105	125	150		
F2 F3 2. T (Blank H1 H2 H3	Without Fail-safe Function Voltage:24V, Deutsch Connecter Voltage:12V, Deutsch Connecter orque Limit Setting (Available only with the attachment of Tor Without Any Torque Limit Setting H Spring, Corner Torque 85% H Spring, Corner Torque 75% H Spring, Corner Torque 65% H Spring, Corner Torque 55% H Spring, Corner Torque 55%	50	65 • •	85	105	125	150 O O O		
F2 F3 2. To Blank H1 H2 H3 H4 M1	Without Fail-safe Function Voltage:24V, Deutsch Connecter Voltage:12V, Deutsch Connecter orque Limit Setting (Available only with the attachment of Tor Without Any Torque Limit Setting H Spring, Corner Torque 85% H Spring, Corner Torque 75% H Spring, Corner Torque 65% H Spring, Corner Torque 55% M Spring, Corner Torque 55% M Spring, Corner Torque 70%	50	65 • • •	85	105	125	150		
E3 F2 F3 2. T(Blank H1 H2 H3 H4 M1 M2	Without Fail-safe Function Voltage:24V, Deutsch Connecter Voltage:12V, Deutsch Connecter orque Limit Setting (Available only with the attachment of Tor Without Any Torque Limit Setting H Spring, Corner Torque 85% H Spring, Corner Torque 75% H Spring, Corner Torque 65% H Spring, Corner Torque 55% M Spring, Corner Torque 55% M Spring, Corner Torque 70% M Spring, Corner Torque 60%	50	65 • •	85	105	125	150 0 0 0 0 0 0 0 0		
E3 F2 F3 2. T(Blank H1 H2 H3 H4 M1 M2 M3	Without Fail-safe Function Voltage:24V, Deutsch Connecter Voltage:12V, Deutsch Connecter orque Limit Setting (Available only with the attachment of Tor Without Any Torque Limit Setting H Spring, Corner Torque 85% H Spring, Corner Torque 75% H Spring, Corner Torque 65% H Spring, Corner Torque 55% M Spring, Corner Torque 55% M Spring, Corner Torque 70%	50	65 • • • •	85	105	125	150		

Code H1 to H4: for torque limit control with power shift control (Additional Control Option Code [11]: "B", "C2", and "C3") Code M1 to M5: for torque limit control without power shift control (Additional Control Option Code [11]: "A")

• : Available

 \bigcirc : Under development

—: Not available

2-1 Specifications

	Size		50	65	85	105	125*1	150
Displacement	t	cm ³	50	65	85	105	125	150
	Rated	MPa			2	8		
Pressure	Peak	MPa			3	5		
Allowable cas	se pres	ssure MPa			0.1 continuo	us / 0.4 peak		
Chood	Self pr	ime*2 min-1	2,700	2,600	2,500	2,300	2,200	2,200
Speed	Maxim	um*³ min-1	3,250	3,000	3,000	2,640	2,400	2,400
Case volume		L	0.8	1.0	1.2	1.7	2.3	2.3
Temperature	range	°C			-20 t	0 +95		
Viscosity ran	ige	cSt		10 to 1,000				
Maximum co	ntamir	nation level	ISO 4406 -/18/15					
		SAE A	123	123	123	123	123	123
		SAE B	380	380	380	380	380	380
Allowable the	rough	SAE BB	435	435	435	435	435	435
drive torque Nm		SAE C	-	435	435	558	435	435
		SAE CC	-	-	-	702	899	899
	SAE D		-	-	-	-	899	899
Mass kg			21	25	31	37	54	52
Moment of inertia kg m ²		2.89×10 ⁻³	5.30×10 ⁻³	6.77×10 ⁻³	9.85×10 ⁻³	1.84×10 ⁻²	1.82×10 ⁻²	
Torsional stif	fness	Nm/rad	4.56×10 ⁴	5.26×10 ⁴	6.79×10 ⁴	1.32×10 ⁵	1.99×10 ⁵	1.99×10 ⁵
Coating	Coating				Red synthetic	resin primer		

^{*1:} Size 125 is under development.

■ Allowable maximum input torque

	SAE B	SAE BB	SAE C	SAE CC	SAE D
Spline specifications	13T 16/32 DP	15T 16/32 DP	14T 12/24 DP	17T 12/24 DP	13T 8/16 DP
Allowable maximum input torque (Nm)	200	315	630	1,060	1,490
Pump size	K3VLS50 K3VLS65	K3VLS50 K3VLS65	K3VLS65 K3VLS85 K3VLS105 K3VLS125 K3VLS150	K3VLS105 K3VLS125 K3VLS150	K3VLS125 K3VLS150

(Note) Maximum pressure must be reduced to operate within the allowable maximum input torque as below when the torque limit control is not used

SAE B spline K3VLS50: 24 MPa K3VLS65: 18 MPa

SAE C spline K3VLS150: 25 MPa

For above options, if 28 MPa is needed, use the torque limit control.

^{*2 :} Self prime speed is the maximum operating speed under the self priming condition at maximum displacement. Steady state inlet pressure should be greater or equal to 0 MPa gauge.

^{*3:} Maximum speed is the maximum operating speed that can run without damage to the pump under restriction of operating conditions.

2-2 Functional Description of Regulator

Load Sensing and Pressure Cut-off


(Ordering Code [9]: L0 / L1)

This regulator has function of flow and pressure control (i.e. load sensing control and pressure cutoff control.)

To control flow a variable orifice is used. (A variable orifice is not included in the pump and shall be prepared separately.) Pump displacement is controlled to maintain the differential pressure across the orifice constant. The flow is controlled to a required flow regardless of pump delivery pressure. In addition, there is a pressure cut off function incorporated into the control. The pressure cut-off function overrides the flow control function.

L0 control: with a bleed off orifice L1 control: without a bleed off orifice

Releasing the pressure at port PL results in standby condition, which provides zero flow at unloading condition. The unloading pressure is typically 0.1 to 0.2 MPa higher than differential pressure setting.



Flow, Pressure control curve

■ Differential pressure setting

Standard setting at factory: 1.5 +0.3/-0.2 MPa Load sensing differential pressure range can be selected from two setting ranges.

unit: MPa


Code	Adjustment range	Adjustment sensitivity
А	1.0 to 3.0	1.3 / turn
С	1.5 to 4.0	2.5 / turn

■ Pressure cut-off setting

Standard setting at factory : 28 O/-1.5 MPa Pressure cut -off setting range is from 5 MPa to 28 MPa.

unit: MPa

Adjustment range	Adjustment sensitivity
5.0 to 28.0	8.0 / turn



Hydraulic circuit

2-2 Functional Description of Regulator

Pressure Cut-off

(Ordering Code [9]: P0)

This regulator has function of pressure control. As discharge pressure rises to the cut-off setting, the pump displacement is reduced to prevent the discharge pressure from exceeding and keep the set pressure. It is imperative that a safety relief valve be installed in the system.

By connecting the Pc port to a remote pressure control relief valve, variable pump pressure control can be achieved.

The remote pressure control relief valve is to be set to 1.5 MPa below to the required system pressure.

The remote control relief valve is out of scope of supply.

■ Differential pressure setting

Standard setting at factory: 1.5 +0.3/-0.2 MPa Load sensing differential pressure range can be selected from two setting ranges.

unit: MPa


Code	Adjustment range	Adjustment sensitivity
А	1.0 to 3.0	1.3 / turn
С	1.5 to 4.0	2.5 / turn

■ Pressure cut-off setting


Standard setting at factory : 28 O/-1.5 MPa Pressure cut -off setting range is from 5 MPa to 28 MPa.

unit: MPa

Adjustment range	Adjustment sensitivity		
5.0 to 28.0	8.0 / turn		



Flow, Pressure control curve



Hydraulic circuit

2-2 Functional Description of Regulator


Torque Limiter

(Ordering Code [11]: A)


LO/L1 control functions as previously noted. In response to a rise in delivery pressure the swash plate angle is decreased, restricting the input torque. This regulator prevents excessive load against the prime mover.

The torque limiter is comprised of two springs that oppose the spool force generated by the system pressure. By turning the adjustment screws, the appropriate input torque limit can be set.

Torque limiter control setting is shown in the attached table, and the torque limiter can be adjusted by the torque value of the table. Refer to the instruction manual for adjustment.



Torque limiter control curve




Hydraulic circuit

2-2 Functional Description of Regulator

Torque Limiter Settings (Ordering Code [11]: A)

■ Pump control curve (sample)



Discharge pressure (MPa)

■ Torque setting without power shift function

	Ordering code [12]				
Pump size	M1	M2	M3	M4	M5
K3VLS50	155	135	110	90	65
K3VLS65	200	175	145	115	85
K3VLS85	265	227	190	150	115
K3VLS105	330	281	235	190	140
K3VLS125	*	*	*	*	*
K3VLS150	*	*	*	*	*

^{*}Size 125 and 150 are under development.

Unit: Nm

2-2 Functional Description of Regulator


Torque Limiter with Power Shift

(Ordering Code [11]: B, C2*, C3*)


Torque limiter is available with variable torque limit control. Torque limit setting can be varied by the external pilot pressure supply (code "B") or the integrated electric proportional control valve with the external servo pressure supply (code "C"). Code "B" and "C" enable to shift the power control setting as shown in the following torque limiter control characteristic curve.

See the table (page 19) for torque setting according to the external pilot pressure or the input current to the integrated proportional valve. Required servo pressure to the solenoid is 3.5 to 4.5 MPa.

(*): Ordering code C2, C3 are under development.




Torque limiter control curve



External pilot pressure (Pf) range: 0 to 4.0 MPa

Hydraulic circuit, code B



Required servo pressure (Psv): 3.5 to 4.5 MPa


Hydraulic circuit, code C

2-2 Functional Description of Regulator

Torque Limiter and Power Shift Settings

(Ordering Code[11]: B, C2*, C3*)

■ Pump control curve with power shift (sample)



Discharge pressure

■ Torque setting with power shift function

Ordering code [11]		Code : B			Code: C2, C3			
		Code . B	Ordering code [12]					
Pump size		Pf	Current (mA) Max. Input torque (Nm)					
		(MPa)	24V C2	12V C3	H1	H2	H3	H4
	1	0.00	()	219	197	170	148
NSVI SEO	2	0.75	290	720	190	170	145	125
K3VLS50	3	2.00	460	1,100	163	142	119	101
	4	3.30	620	1,450	134	115	94	78
	1	0.00	0		283	249	217	190
K3VLS65	2	0.75	290	720	245	215	185	160
KSVLS0S	3	2.00	460	1,100	210	181	151	129
	4	3.30	620	1,450	175	146	120	100
	1	0.00	()	375	331	287	244
K3VLS85	2	0.75	290	720	325	285	245	205
K3VL303	3	2.00	460	1,100	279	239	200	164
	4	3.30	620	1,450	231	193	159	127
	1	0.00	0		455	406	357	308
K3VLS105	2	0.75	290	720	395	350	305	260
K2AF2102	3	2.00	460	1,100	338	293	250	209
	4	3.30	620	1,450	279	236	198	162
	1	*	,	k	*	*	*	*
K3VLS125	2	*	*	*	*	*	*	*
K3VL3125	3	*	*	*	*	*	*	*
	4	*	*	*	*	*	*	*
	1	*	*		*	*	*	*
K3VLS150	2	*	*	*	*	*	*	*
K3VL313U	3	*	*	*	*	*	*	*
	4	*	*	*	*	*	*	*

Input torque in the above table is planned value and for reference.

^{*}Size 125 and 150 are under development.

2-2 Functional Description of Regulator

Electric Displacement Control (Positive Control)


- With Fail-safe Function (Ordering Code[11]: E2, E3)
- Without Fail-safe Function (Ordering Code[11]: F2, F3)

The electric displacement control enables the pump displacement to be changed according to the change of input current to the solenoid. The pump displacement can be adjusted in proportion to the input current between the input current of $\rm I_1$ and $\rm I_2$ (refer to control curve).

With fail-safe function, at loss of input current in such case of brakage of electric wires, the pump displacement becomes maximum automatically. Even under this condition the load sensing and pressure cut-off control can be operated.

The fail-safe function is designed only for usage in short period for emergency. Necessary repair is to be made in the soonest opportunity.

For the hydraulic circuit refer to page 21.



Unit: mA

Ordering code	I ₁	I ₂
E2, F2	200	600
E3, F3	400	1,200

■ Note for pumps with fail-safe

■ Note for start up

Due to its structure, the electric displacement control requires larger input current than I_2 at start up, then normal proportional control can be achieved between I_1 and I_2 .

■ Minimum operating pressure

With fail-safe function, in order to ensure safety and repeatability of control the minimum operating pressure of 5 MPa is to be secured. This avoids switching the pump to fail-safe mode unexpectedly.

■ Input current ramp time requirement

With fail-safe function (Ordering code: E2, E3), ramp time of 200 msec or larger is to be secured.

■ Recommended dither condition for the input current


Dither frequency: 150 Hz

Dither amplitude: for E2, F2 200 mA $_{\rm p-p}$ for E3, F3 400 mA $_{\rm p-p}$

	E2, F2	E3, F3
Rated current [mA]	700	1,400
Coil resistance (at 20℃) [Ω]	22.6	5.7
Power consumption (at 20℃) [W]	11.2	11.2
Connector type		tribution 4-2P
Water proof	IP67	


2-2 Functional Description of Regulator

- **Electric Displacement Control (Positive Control)**
 - With Fail-safe Function (Ordering Code[11]: E2, E3)
 - Without Fail-safe Function (Ordering Code[11]: F2, F3)



Spool 1: Electric Flow Control Valve Spool 2: Differential Spool Spool 3: Cut-off Spool

Hydraulic Circuit With Fail-safe Function



Spool 1: Electric Flow Control Valve Spool 2: Differential Spool Spool 3: Cut-off Spool

Hydraulic Circuit Without Fail-safe Function


3-1 Installation Dimensions


* Dimensions in mm.

★ K3VLS50 with Cut-off/Load Sense Control, Side Port (Clockwise Rotation)

Model Code : <u>K3VLS 50 - 1 0 R BB * - L0 A</u>

: <u>K3VLS 50 - 1 0 R BB * - L1 A</u> : <u>K3VLS 50 - 1 0 R BB * - P0 A</u>






3-1 Installation Dimensions


* Dimensions in mm.

K3VLS50 with Torque Limit Control, Side Port (Clockwise Rotation)

Model Code: <u>K3VLS 50 - 1 0 R BB * - L0 A A</u>

: <u>K3VLS 50 - 1 0 R BB * - L1 A A</u> : <u>K3VLS 50 - 1 0 R BB * - P0 A A</u>






3-1 Installation Dimensions

* Dimensions in mm.

★ K3VLS50 Torque Limit with Power Shift Control, Side Port (Clockwise Rotation)

Model Code : $\underline{K3VLS} \underline{50} - \underline{1} \underline{N} \underline{R} \underline{BB} \underline{*} - \underline{L0} \underline{A} \underline{B}$

: K3VLS 50 - 1 N R BB * - L1 A B : K3VLS 50 - 1 N R BB * - P0 A B




* Dimensions in mm.

3-1 Installation Dimensions

★ K3VLS50 Electric Displacement Control, Side Port (Clockwise Rotation)

Model Code : $\underline{K3VLS} \underline{50} - \underline{1} \underline{0} \underline{R} \underline{BB} \underline{*} - \underline{L0} \underline{A} \underline{E} \text{ or } - \underline{L0} \underline{A} \underline{F}$

: <u>K3VLS 50 - 1 0 R BB * - L1 A E or - L1 A F</u> : <u>K3VLS 50 - 1 0 R BB * - P0 A E or - P0 A F</u>




3-1 Installation Dimensions


*Dimensions in mm.

★ K3VLS50 Rear Port (Clockwise Rotation)

Model Code : <u>K3VLS 50 - 1 R R BB * - L0 A</u> : <u>K3VLS 50 - 1 R R BB * - L1 A</u>

: K3VLS 50 - 1 R R BB * - PO A







★ K3VLS50 Torque Limit Control, Rear Port (Clockwise Rotation)

Model Code : $\underline{\text{K3VLS}} \ \underline{50} - \underline{1} \ \underline{\text{R}} \ \underline{\text{R}} \ \underline{\text{BB}} \ \underline{*} - \underline{\text{L0}} \ \underline{\text{A}} \ \underline{\text{A}}$

: K3VLS 50 - 1 R R BB * - L1 A A : K3VLS 50 - 1 R R BB * - P0 A A






3-1 Installation Dimensions


* Dimensions in mm.

K3VLS50 Mounting Flange and Shaft Options

SAE BB Spline Shaft
Ordering Code "7. Mounting Flange and Shaft": BB

SAE B Spline Shaft
Ordering Code "7. Mounting Flange and Shaft": B





Tightening torque (Nm)

Involute spline according to ANSI B92.1a, 30° pressure angle, flat root, side fit.

K3VLS50 Porting Details

Main SAE Flanged Ports

Port name	Port size Flange threads		Tightening torque (Nm)			
UNF Threaded Version ('S' in position 8 of model code)						
Delivery port	SAE J518C std pressure (code 61) 1"	3/8-16UNC-2B-18	57			
Suction port	SAE J518C std pressure (code 61) 1-1/2"	1/2-13UNC-2B-22	98			
Metric Version ('H' in position 8 of model code)						
Delivery port	PORT ISO 6162-1: 2012 P25M	M10-17	57			
Suction port	PORT ISO 6162-1: 2012 P38M	M12-20	98			
	Threaded Version ('S' in po Delivery port Suction port Version ('H' in position 8 Delivery port	Threaded Version ('S' in position 8 of model code) Delivery port SAE J518C std pressure (code 61) 1" Suction port SAE J518C std pressure (code 61) 1-1/2" Version ('H' in position 8 of model code) Delivery port PORT ISO 6162-1: 2012 P25M	Threaded Version ('S' in position 8 of model code) Delivery port SAE J518C std pressure (code 61) 1" 3/8-16UNC-2B-18 Suction port SAE J518C std pressure (code 61) 1-1/2" 1/2-13UNC-2B-22 Version ('H' in position 8 of model code) Delivery port PORT ISO 6162-1: 2012 P25M M10-17			

Auxiliary Ports

Port name

Des

SAE Version					
Dr	Drain port	3/4-16UNF-2B-14.3 (ISO 11926-1: 1995)	98		
PL	Load sensing port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12		
Pc	Pressure control port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12		
a	Gauge port	9/16-18UNF-2B-12.7 (ISO 11926-1: 1995)	59		
Psv	Servo pressure port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12		
Pf	Power shift pressure port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12		


Port size

3-1 Installation Dimensions


* Dimensions in mm.

K3VLS50 Through Drive Options

Through Drive SAE A
Ordering Code "5. Through Drive and Porting": A



Through Drive SAE B
Ordering Code "5. Through Drive and Porting": B




Involute spline according to ANSI B92.1a, 30° pressure angle, flat root, side fit.

3-1 Installation Dimensions

*Dimensions in mm.

K3VLS50 Through Drive Options

Through Drive SAE BB Ordering Code "5. Through Drive and Porting": BB




3-1 Installation Dimensions

* Dimensions in mm.

★ K3VLS65 with Cut-off / Load Sense Control, Side Port (Clockwise Rotation)

Model Code: K3VLS 65 - 1 0 R BB * - L0 A

: K3VLS 65 - 1 0 R BB * - L1 A : K3VLS 65 - 1 0 R BB * - P0 A




* Dimensions in mm.

3-1 Installation Dimensions

★ K3VLS65 Torque Limit Control, Side Port (Clockwise Rotation)

Model Code: K3VLS 65 - 1 0 R BB * - L0 A A

: K3VLS 65 - 1 0 R BB * - L1 A A : K3VLS 65 - 1 0 R BB * - P0 A A




3-1 Installation Dimensions

* Dimensions in mm.

★ K3VLS65 Torque Limit with Power Shift Control, Side Port (Clockwise Rotation)

Model Code: K3VLS 65 - 1 0 R BB * - L0 A B

: K3VLS 65 - 1 0 R BB * - L1 A B : K3VLS 65 - 1 0 R BB * - P0 A B




*Dimensions in mm.

3-1 Installation Dimensions

★ K3VLS65 with Cut-off Load Sense Control, Side Port (Clockwise Rotation, SAE C-4 Mount Type)

Model Code : $\underline{K3VLS} \underline{65} - \underline{1} \underline{0} \underline{R} \underline{C} * - \underline{L0} \underline{A}$

: <u>K3VLS 65 - 1 0 R C * - L1 A</u> : <u>K3VLS 65 - 1 0 R C * - P0 A</u>



Involute spline according to ANSI B92.1a, 30° pressure angle, flat root, side fit.


3-1 Installation Dimensions

*Dimensions in mm.

★ K3VLS65 Electric Displacement Control , Side Port (Clockwise Rotation)

Model Code : $\underline{\text{K3VLS}}$ $\underline{65}$ - $\underline{1}$ $\underline{0}$ $\underline{\text{R}}$ $\underline{\text{BB}}$ $\underline{*}$ - $\underline{\text{L0}}$ $\underline{\text{A}}$ $\underline{\text{E}}$ or - $\underline{\text{L0}}$ $\underline{\text{A}}$ $\underline{\text{F}}$

: <u>K3VLS 65 - 1 0 R BB * - L1 A E or - L1 A F</u> : <u>K3VLS 65 - 1 0 R BB * - P0 A E or - P0 A F</u>




3-1 Installation Dimensions

* Dimensions in mm.

K3VLS65 Rear Port (Clockwise Rotation)

Model Code: <u>K3VLS 65 - 1 R R BB * - LO A</u>


: <u>K3VLS 65 - 1 R R BB * - L1 A</u> : <u>K3VLS 65 - 1 R R BB * - P0 A</u>




★ K3VLS65 Torque Limit Control, Rear Port (Clockwise Rotation)

Model Code : $\underline{K3VLS} \underline{65} - \underline{1} \underline{R} \underline{R} \underline{BB} \underline{*} - \underline{L0} \underline{A} \underline{A}$

: K3VLS 65 - 1 R R BB * - L1 A A : K3VLS 65 - 1 R R BB * - PO A A






3-1 Installation Dimensions


* Dimensions in mm.

K3VLS65 Mounting Flange and Shaft Options

SAE BB Spline Shaft
Ordering Code "7. Mounting Flange and Shaft": BB

SAE B Spline Shaft
Ordering Code "7. Mounting Flange and Shaft": B





Involute spline according to ANSI B92.1a, 30° pressure angle, flat root, side fit.

K3VLS65 Porting Details

Main SAE Flanged Ports

Des	Port name	Port size	Flange threads	Tightening torque (Nm)			
UNF T	UNF Threaded Version ('S' in position 8 of model code)						
Α	Delivery port	SAE J518C std pressure (code 61) 1"	3/8-16UNC-2B-18	57			
В	Suction port	SAE J518C std pressure (code 61) 2"	1/2-13UNC-2B-22	98			
Metri	c Version ('H' in position 8	of model code)					
А	Delivery port	PORT ISO 6162-1: 2012 P25M	M10-17	57			
В	Suction port	PORT ISO 6162-1: 2012 P51M	M12-20	98			

Auxiliary Ports

Des	Port name	Port size	Tightening torque (Nm)
-----	-----------	-----------	------------------------


SAE Version

Dr	Drain port	3/4-16UNF-2B-14.3 (ISO 11926-1: 1995)	98
PL	Load sensing port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12
Pc	Pressure control port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12
а	Gauge port	9/16-18UNF-2B-12.7 (ISO 11926-1: 1995)	59
Psv	Servo pressure port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12
Pf	Power shift pressure port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12


* Dimensions in mm.

K3VLS65 Through Drive Options

Through Drive SAE A
Ordering Code "5. Through Drive and Porting": A



Through Drive SAE B
Ordering Code "5. Through Drive and Porting": B




3-1 Installation Dimensions


*Dimensions in mm.

K3VLS65 Through Drive Options

Through Drive SAE BB
Ordering Code "5. Through Drive and Porting": BB



Through Drive SAE C
Ordering Code "5. Through Drive and Porting": C




* Dimensions in mm.

★ K3VLS85 with Cut-off / Load Sense Control, Side Port (Clockwise Rotation)

Model Code: <u>K3VLS 85</u> - <u>1 0 R C * - L0 A</u>

: <u>K3VLS 85 - 1 0 R C * - L1 A</u> : <u>K3VLS 85 - 1 0 R C * - P0 A</u>



Involute spline according to ANSI B92.1a, 30° pressure angle, flat root, side fit. (**) With a through drive is 86 mm


3-1 Installation Dimensions

* Dimensions in mm.

★ K3VLS85 Torque Limit Control, Side Port (Clockwise Rotation)

Model Code : $\underline{K3VLS} \ \underline{85} - \underline{1} \ \underline{0} \ \underline{R} \ \underline{C} \ \underline{*} \ - \underline{L0} \ \underline{A} \ \underline{A}$

: K3VLS 85 - 1 0 R C * - L1 A A : K3VLS 85 - 1 0 R C * - P0 A A




*Dimensions in mm.

3-1 Installation Dimensions

★ K3VLS85 Torque Limit with Power Shift Control, Side Port (Clockwise Rotation)

Model Code: <u>K3VLS 85 - 1 0 R C * - L0 A B</u>

: <u>K3VLS 85 - 1 0 R C * - L1 A B</u> : <u>K3VLS 85 - 1 0 R C * - P0 A B</u>




3-1 Installation Dimensions

* Dimensions in mm.

★ K3VLS85 Rear Port (Clockwise Rotation)


Model Code: <u>K3VLS 85 - 1 R R C * - L0 A</u> : <u>K3VLS 85 - 1 R R C * - L1 A</u> : <u>K3VLS 85 - 1 R R C * - P0 A</u>



★ K3VLS85 Torque Limit Control, Rear Port (Clockwise Rotation)

Model Code : $\underline{K3VLS} \ \underline{85} - \underline{1} \ \underline{R} \ \underline{R} \ \underline{C} \ \underline{*} - \underline{L0} \ \underline{A} \ \underline{A}$

: <u>K3VLS 85 - 1 R R C * - L1 A A</u> : <u>K3VLS 85 - 1 R R C * - P0 A A</u>



3-1 Installation Dimensions

K3VLS85 Porting Details

Main SAE Flanged Ports

Des	Port name	Port size	Flange threads	Tightening torque (Nm)			
UNF Threaded Version ('S' in position 8 of model code)							
А	Delivery port	SAE J518C high pressure (code 62) 1-1/4"	1/2-13UNC-2B-22	98			
В	Suction port	SAE J518C std pressure (code 61) 2-1/2"	1/2-13UNC-2B-22	98			
Metri	c Version ('H' in position 8	of model code)					
Α	Delivery port	PORT ISO 6162-2: 2012 P32M	M12-23	98			
В	Suction port	PORT ISO 6162-1: 2012 P64M	M12-22	98			

Auxiliary Ports


Des	Port name	Port size	Tightening torque (Nm)			
SAE V	SAE Version					
Dr	Drain port	3/4-16UNF-2B-14.3 (ISO 11926-1: 1995)	98			
PL	Load sensing port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12			
Pc	Pressure control port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12			
а	Gauge port	9/16-18UNF-2B-12.7 (ISO 11926-1: 1995)	59			
Psv	Servo pressure port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12			
Pf	Power shift pressure port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12			

3-1 Installation Dimensions


* Dimensions in mm.

K3VLS85 Through Drive Options

Through Drive SAE A
Ordering Code "5. Through Drive and Porting": A




Through Drive SAE B
Ordering Code "5. Through Drive and Porting": B




* Dimensions in mm.

K3VLS85 Through Drive Options

Through Drive SAE BB
Ordering Code "5. Through Drive and Porting": BB



Trough Drive SAE C
Ordering Code "5. Through Drive and Porting": C




3-1 Installation Dimensions


* Dimensions in mm.

K3VLS105 with Cut-off / Load sense Control, Side Port (Clockwise Rotation)

Model Code: <u>K3VLS</u> <u>105</u> - <u>1</u> <u>0</u> <u>R</u> <u>CC</u> * - <u>L0</u> <u>A</u>

: <u>K3VLS 105 - 1 0 R CC * - L1 A</u> : <u>K3VLS 105 - 1 0 R CC * - P0 A</u>






*Dimensions in mm.

3-1 Installation Dimensions

★ K3VLS105 Torque Limit Control, Side Port (Clockwise Rotation)

Model Code : $\underline{K3VLS} \underline{105} - \underline{1} \underline{0} \underline{R} \underline{CC} \underline{*} - \underline{L0} \underline{A} \underline{A}$

: <u>K3VLS 105 - 1 0 R CC * - L1 A A</u> : <u>K3VLS 105 - 1 0 R CC * - P0 A A</u>




3-1 Installation Dimensions

* Dimensions in mm.

K3VLS105 Torque Limit with Power Shift Control, Side Port (Clockwise Rotation)

Model Code : $\underline{\text{K3VLS}} \ \underline{105} - \underline{1} \ \underline{0} \ \underline{\text{R}} \ \underline{\text{CC}} \ \underline{*} - \underline{\text{L0}} \ \underline{\text{A}} \ \underline{\text{B}}$

: <u>K3VLS 105 - 1 0 R CC * - L1 A B</u> : <u>K3VLS 105 - 1 0 R CC * - P0 A B</u>




* Dimensions in mm.

K3VLS105 Rear Port (Clockwise Rotation)

Model Code: <u>K3VLS 105 - 1 R R CC * - L0 A</u> : <u>K3VLS 105 - 1 R R CC * - L1 A</u>


: <u>K3VLS 105 - 1 R R CC * - P0 A</u>




★ K3VLS105 Torque Limit Control, Rear Port (Clockwise Rotation)

Model Code : $\underline{K3VLS} \underline{105} - \underline{1} \underline{R} \underline{R} \underline{CC} \underline{*} - \underline{L0} \underline{A} \underline{A}$

: <u>K3VLS 105 - 1 R R CC * - L1 A A</u> : <u>K3VLS 105 - 1 R R CC * - P0 A A</u>






3-1 Installation Dimensions


* Dimensions in mm.

K3VLS105 Mounting Flange and Shaft Options

SAE CC Spline Shaft
Ordering Code "7.Mounting Flange and Shaft": CC

SAE C Spline Shaft
Ordering Code "7.Mounting Flange and Shaft": C





Involute spline according to ANSI B92.1a, 30° pressure angle, flat root, side fit.

K3VLS105 Porting Details

Main SAE Flanged Ports

IVIGITI	Wall SAL Hangea Forts							
Des	Port name	Port size	Flange threads	Tightening torque (Nm)				
UNF 1	UNF Threaded Version ('S' in position 8 of model code)							
Α	Delivery port	SAE J518C high pressure (code 62) 1-1/4"	1/2-13UNC-2B-22	98				
В	Suction port	SAE J518C std pressure (code 61) 2-1/2"	1/2-13UNC-2B-22	98				
Metri	c Version ('H' in position 8	of model code)						
А	Delivery port	PORT ISO 6162-2: 2012 P32M	M12-23	98				
В	Suction port	PORT ISO 6162-1: 2012 P64M	M12-22	98				
Auvili	ary Ports							

Auxiliary Ports


Des	Port name	Port size	Tightening torque (Nm)				
SAF Version							

Dr	Drain port	1-1/16-12UN-2B-19 (ISO 11926-1: 1995)	167
PL	Load sensing port 7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)		12
Pc	Pressure control port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12
а	Gauge port	9/16-18UNF-2B-12.7 (ISO 11926-1: 1995)	59
Psv	Servo pressure port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12
Pf	Power shift pressure port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12


* Dimensions in mm.

★ K3VLS105 Through Drive Options

Through Drive SAE A
Ordering Code "5. Through Drive and Porting": A



Through Drive SAE B
Ordering Code "5. Through Drive and Porting": B




3-1 Installation Dimensions


* Dimensions in mm.

K3VLS105 Through Drive Options

Through Drive SAE BB
Ordering Code "5. Through Drive and Porting": BB



Through Drive SAE C
Ordering Code "5. Through Drive and Porting": C




3-1 Installation Dimensions

*Dimensions in mm.

K3VLS105 Through Drive Options

Through Drive SAE CC
Ordering Code "5. Through Drive and Porting": CC



3-1 Installation Dimensions

* Dimensions in mm.

★ K3VLS125/150 with Cut-off/Load Sense Control, Side Port (Clockwise Rotation)


Model Code: <u>K3VLS 125 - 1 0 R D * - L0 A</u>

: <u>K3VLS 125 - 1 0 R D * - L1 A</u>

: <u>K3VLS 150 - 1 0 R D * - L1 A</u>

: <u>K3VLS 150 - 1 0 R D * - L1 A</u>

: K3VLS 125 - 1 0 R D * - P0 A : K3VLS 150 - 1 0 R D * - P0 A



* Dimensions in mm.

★ K3VLS125/150 with Cut-off/Load Sense Control, Side Port (Clockwise Rotation, SAE C-4 Mount Type)


Model Code : <u>K3VLS 125 - 1 0 R CC * - L0 A</u>


: <u>K3VLS 125 - 1 0 R CC * - L1 A</u>

: <u>K3VLS 150 - 1 0 R CC * - L1 A</u>

: <u>K3VLS 150 - 1 0 R CC * - L1 A</u>

: K3VLS 125 - 1 0 R CC * - P0 A : K3VLS 150 - 1 0 R CC * - P0 A





3-1 Installation Dimensions

* Dimensions in mm.

★ K3VLS125 /150 Rear Port (Clockwise Rotation, SAE C-4 Mount Type)

Model Code : <u>K3VLS 125 - 1 R R C * - L0 A</u>


: <u>K3VLS 125 - 1 R R C * - L1 A</u>

: <u>K3VLS 125 - 1 R R C * - L1 A</u>

: <u>K3VLS 150 - 1 R R C * - L1 A</u>

: <u>K3VLS 150 - 1 R R C * - P0 A</u>

: <u>K3VLS 150 - 1 R R C * - P0 A</u>




★ K3VLS125 /150 Rear Port (Clockwise Rotation, SAE D Mount Type)

Model Code: <u>K3VLS 125 - 1 R R D * - L0 A</u> Model Code: <u>K3VLS 150 - 1 R R D * - L0 A</u>

 : K3VLS 125 - 1 R R D * - L1 A
 : K3VLS 150 - 1 R R D * - L1 A

 : K3VLS 125 - 1 R R D * - P0 A
 : K3VLS 150 - 1 R R D * - P0 A





* Dimensions in mm.

★ K3VLS125/150 Mounting Flange and Shaft Options

SAE CC Spline Shaft
Ordering Code "7. Mounting Flange and Shaft": CC

SAE C Spline Shaft
Ordering Code "7. Mounting Flange and Shaft": C





Tightening torque (Nm)

Involute spline according to ANSI B92.1a, 30° pressure angle, flat root, side fit.

★ K3VLS125/150 Porting Details

Main SAE Flanged Ports

	Ham S. E. Hambea F. O. C.							
Des	Port name	Port size	Flange threads	Tightening torque (Nm)				
UNF 1	UNF Threaded Version ('S' in position 8 of model code)							
Α	Delivery port	SAE J518C high pressure (code 62) 1-1/4"	1/2-13UNC-2B-22	98				
В	Suction port	SAE J518C std pressure (code 61) 2-1/2"	1/2-13UNC-2B-22	98				
Metri	c Version ('H' in position 8	of model code)						
Α	Delivery port	PORT ISO 6162-2:2012 P32M	M12-23	98				
В	Suction port	PORT ISO 6162-1:2012 P64M	M12-23	98				
	Dt-		•	•				

Auxiliary Ports

Port name

Des

SAE Version					
Dr	Drain port	1-1/16-12UN-2B-19 (ISO 11926-1: 1995)	167		
PL	Load sensing port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12		
Pc	Pressure control port	7/16-20UNF-2B-11.5 (ISO 11926-1: 1995)	12		
a	Gauge port	9/16-18UNF-2B-12.7 (ISO 11926-1: 1995)	59		
Psv	Servo pressure port	7/16-20UNF-2B-11.5 (ISO 11926-1:1995)	12		
Pf	Power shift pressure port	7/16-20UNF-2B-11.5 (ISO 11926-1:1995)	12		


Port size

3-1 Installation Dimensions


* Dimensions in mm.

★ K3VLS125/150 Through Drive Options

Through Drive SAE B
Ordering Code "5. Through Drive and Porting": B




Through Drive SAE BB
Ordering Code "5. Through Drive and Porting": BB




* Dimensions in mm.

★ K3VLS125/150 Through Drive Options

Through Drive SAE C
Ordering Code "5. Through Drive and Porting": C



Through Drive SAE CC
Ordering Code "5. Through Drive and Porting": CC



3-2 Installation of Auxiliary Pumps

■ Allowable mass moment for combination pump

K3VLS series can consist of multiple pumps using through drive mounting. The second pump can be attached up to the same size of the first pump. The table below shows the maximum allowable mass moment to the mounting flange of the first pump under the dynamic acceleration of 10G. The moment can be calculated by the formula shown below.

	K3VLS50 K3VLS65		K3VLS85		K3VLS105		K3VLS 125*1/150	K3VLS 125*1/150	
	SAE B mount	SAE B mount	SAE C mount	SAE C-2 mount	SAE C-4 mount	SAE C-2 mount	SAE C-4 mount	SAE C mount	SAE D mount
Allowable mass moment Tm (Nm) (dynamic acceleration of 10G)	180	210	330	280	410	280	410	500	680


^{*1:} Size 125 is under development.

■ Calculation formula for mass moment

 $Tm = (m1 \times L1 + m2 \times L2 + m3 \times L3 + \cdots) \times 1 / 102$

m1, m2, m3 \cdots : Weight of pump [kg] L1, L2, L3 \cdots : Center of gravity [mm]

See next page for values.



■ Values for calculation of mass moment

Through drive size ported		Length, weight	50	65 SAE B mount	65 SAE C mount	85	105	125*/150 SAE C mount	125*/150 SAE D mount
	Total leng	gth L (mm)	214	239	239	271	274	331	301
		gravity L1 unting face: mm)	107	117	113	126	131	166	139
	Weight	with torque limiter	24	28	29	34	40	* 1	* 1
	(kg)	without torque limiter	21	25	26	31	37	54	52
	Total leng	gth L (mm)	188	207	207	232	237	300	270
		gravity L1 unting face: mm)	101	111	108	120	123	161	134
'	Weight	with torque limiter	23	27	28	33	39	*1	*1
	(kg)	without torque limiter	20	24	25	29	35	53	51
	Total length L (mm)		234	253	253	281	286	* 1	*1
SAEA	Center of gravity L1 (from mounting face: mm)		116	129	126	136	137	*1	* 1
JAE A	Weight (kg)	with torque limiter	26	31	32	37	42	* 1	*1
		without torque limiter	23	28	29	33	39	*1	* 1
	Total length L (mm)		261	280	280	308	313	348	318
SAE B	Center of gravity L1 (from mounting face: mm)		133	146	142	152	152	182	155
SAE BB	Weight	with torque limiter	29	35	35	41	46	* 1	*1
	(kg)	without torque limiter	26	31	32	37	43	60	58
	Total leng	gth L (mm)	_	_	278	314	319	375	345
SAE C		gravity L1 unting face: mm)	_	_	150	157	156	198	171
	Weight	with torque limiter	_	_	37	42	47	* 1	*1
	(kg)	without torque limiter	_	_	35	38	44	66	64
	Total leng	gth L (mm)	_	_	_	_	-	*1	*1
CAED		gravity L1 unting face: mm)	_	_	_	_	_	*1	*1
SAE D	Weight	with torque limiter	-	_	-	-	-	*1	* 1
	(kg)	without torque limiter	_	_	_	_	_	*1	*1

 $[\]ensuremath{ \star } 1$: Size 125 and 150 are under development.

Please fill the table to specify the requirements. Please contact us for any questions.

K3VLS Series Inquiry Form

Kawasaki Powering your potential

Please tick the box for options.						Dā	Date:			1	Machine Model:				
Options with ★ are under development.					Ap	Application:									
Swash Plate Type Axial Piston Pump							Customer Name:								
Γ	Model Code	1	2	3	4	5	6	7	8		9	10	11	12	
	Model Code	1/2/// C		İ	-1			İ			İ	İ			

Items	Model Code No.	Requirements		comment		
	COUC INU.	50				
	2	65				
Pump Size		85				
1 6111p 312c		105				
		125	□ *			
Series Specification	4	150 1 : Standard Type				
series specification	4	1 : Standard Type 0 : Without Through Drive, Side Ported				
	5	A : SAE A Through Drive, Side Ported (Size 125 and 150 are under development.)				
		B : SAE B Through Drive, Side Ported				
		BB : SAE BB Through Drive, Side Ported				
Through Drive and Porting		C : SAE C 2/4 bolt Through Drive, Side Ported (for K3VLS65 / 85 / 105 / 125 / 150)				
		CC : SAE CC 2/4 bolt Through Drive, Side Ported (for K3VLS105 / 125 / 150)				
		D : SAE D Through Drive, Side Ported (for K3VLS125 / 150)	□ ★			
		N : With Through Drive Shaft, Without Coupling, Closed with Steel Cover, Side Ported				
		R : Without Through Drive, Rear Ported (Size 125 is under development.)				
Direction of Rotation	7	R : Clockwise L : Counterclockwise				
		B : SAE B Mount & SAE B Spline (for K3VLS50 / 65)				
		BB : SAE B Mount & SAE BB Spline (for K3VLS50 / 65)				
Mounting Flance and Chaft		SAE C Mount & SAE C Spline (for K3VLS65/ 85 / 105/ 125/ 150)				
Mounting Flange and Shaft		**Only SAE C-4 mount for K3VLS65, 125 & 150 SAE C Mount & SAE CC Spline (for K3VLS105/ 125/ 150)				
		CC : *Only SAE C-4 mount for K3VLS125 & 150				
		D : SAE D Mount & SAE D Spline (for K3VLS125 / 150)				
Flange Fixing Thread	8	S : SAE 4-bolt Flange, UNC Threaded				
(Suction/Delivery)	_	H : SAE 4-bolt Flange, Metric Threaded				
		Load Sense & Pressure Cut-off				
Flow Control	9	L0 : With LS Bleed-off Orifice L1 : Without LS Bleed-off Orifice				
		PO : Pressure Cut-off				
Differential Pressure Setting Range		A : Standard Setting Range (1.0 to 3.0 MPa)				
(For the details see page 14)	10	C : High Setting Range (1.5 to 4.0 MPa)				
		Blank : Without Any Additional Control	Size 125 and 150 are			
		Torque Limit Control	under develolpment.			
		A : Without Power Shift Control				
	11	B : With Power Shift Control Pilot Operated				
		C2 : With Electric Proportional Reducing Valve, Voltage : 24V, Deutsch Connecter	□ ★			
Additional Control Options (For the additional control options		C3 : With Electric Proportional Reducing Valve, Voltage : 12V, Deutsch Connecter Electric Displacement Control (Positive Control)	□ ★			
"11", only one option per column is		Voltage · 24V Deutsch Connecter				
acceptable.)		Electric Proportional Solenoid E2 + (for K3VI S50 / 65 / 85)				
		with fail-safe function "Size 85 is under development E3 : Voltage : 12V, Deutsch Connecter (for K3VLS50 / 65 / 85)				
		Electric Proportional Solenoid without fail-safe function "Size" F2 : Voltage : 24V, Deutsch Connecter				
		85,105,125 and 150 are under development F3: Voltage: 12V, Deutsch Connecter				
	12	Blank : Without Any Torque Limit Setting		Size 125 and 150 are		
		H1 : H Spring, Corner Torque 85%	under development.			
		H2 : H Spring, Corner Torque 75%				
Tanana Limit Catting		H3 : H Spring, Corner Torque 65%				
Torque Limit Setting (Available only with the attachment		H4 : H Spring, Corner Torque 55%				
of Torque Limiter)	_	M1 : M Spring, Corner Torque 70%				
		M2 : M Spring, Corner Torque 60%				
		M3 : M Spring, Corner Torque 50% M4 : M Spring, Corner Torque 40%				
		M5 : M Spring, Corner Torque 40%	<u></u>			
				<u> </u>		

Operating condition, Duty cycle etc. (Describe your detail)				
Note				

Kawasaki Heavy Industries, Ltd.

Precision Machinery Business Division

http://www.khi.co.jp/kpm/

Tokyo Head Office

1-14-5 Kaigan, Minato-ku, Tokyo 105-8315, Japan Phone +81-3-3435-6862 Fax. +81-3-3435-2023

Kobe Head Office

Kobe Crystal Tower, 1-3 Higashikawasaki-cho 1-chome, Chuo-ku, Kobe 650-8680, Japan

Phone +81-78-360-8607 Fax. +81-78-360-8609

Nishi-kobe Works

234, Matsumoto, Hasetani-cho, Nishi-ku, Kobe 651-2239, Japan Phone +81-78-991-1160 Fax. +81-78-991-3186

OVERSEAS SUBSIDIARIES

Kawasaki Precision Machinery (UK) Ltd.

Ernesettle Lane, Ernesettle, Plymouth, Devon, PL5 2SA United Kingdom Phone +44-1752-364394 Fax. +44-1752-364816 http://www.kpm-eu.com

Kawasaki Precision Machinery (U.S.A.), Inc.

3838 Broadmoor Avenue S.E. Grand Rapids, Michigan 49512, U.S.A. Phone +1-616-975-3100 Fax. +1-616-975-3103 http://www.kpm-usa.com

Kawasaki Precision Machinery (Suzhou) Ltd.

668 JianLin Rd, New District, Suzhou, 215151 China Phone +86-512-6616-0365 Fax. +86-512-6616-0366

Kawasaki Precision Machinery Trading (Shanghai) Co., Ltd.

17th Floor (Room 1701), The Headquarters Building, No168, XiZang Road (M), Huangpu District, Shanghai, 200001, China Phone +86-21-3366-3800 Fax. +86-21-3366-3808

Kawasaki Chunhui Precision Machinery (Zhejiang) Ltd.

No.200 Yasha Road Shangyu Economic Development Zone, Shansyu, Zhejiang, 312300, China

Phone +86-575-8215-6999 Fax. +86-575-8215-8699

Flutek, Ltd.

192-11, Shinchon-dong, Changwon, Kyungnam, 51567, Korea Phone +82-55-210-5900 Fax. +82-55-286-5557

Wipro Kawasaki Precision Machinery Private Limited

No. 15, Sy. No. 35 & 37, Kumbalgodu Industrial Area, Kumbalgodu Village, Kengeri Hobli, Bangalore, – 560074 ,India



QR code
Precision Machinery
Company Website